

ON THE RESEARCH AREAS OF APPROACH FLOW SYSTEMS

Project F004

Report 1

to the

MEMBER COMPANIES OF THE INSTITUTE OF PAPER SCIENCE AND TECHNOLOGY

March 1996

INSTITUTE OF PAPER SCIENCE AND TECHNOLOGY

Atlanta, Georgia

ON THE RESEARCH AREAS OF APPROACH FLOW SYSTEMS

Project F004

Report 1

A Progress Report

to the

MEMBER COMPANIES OF THE INSTITUTE OF PAPER SCIENCE AND TECHNOLOGY

By

Wang, X.

March 1996

Executive Summary

Institute of Paper Science and Technology

In this report, the results from the informal survey on the research areas of approach pipe systems are summarized. Current guidelines from TAPPI Technical Information Sheet (TIS), Valmet, Voith, and Beloit are also reviewed and discussed. Based on the survey results and the available information of the past research done in this area, after having completed many telephone interviews, field trips in the three major papermaking machine suppliers, and several mill visits, let alone dozens of papers in this field, it is concluded worthwhile to establish a corresponding funded project on approach pipe systems at IPST. The objectives of this project are to solve some immediate problems relating to approach pipe systems and to obtain deeper fundamental understanding that can be used in the future designs. Specifically, based on the state-of-art computational procedures and the development of concepts in fluidics and hydraulics, computer simulations of different approach flow components and their interactions within the whole system will be developed and analyzed. Some softwares for analyzing and optimizing the approach flow systems according to different mill conditions are to be delivered through this research project.

The project will provide general information for all of our membership companies and focus on the fundamental research of our paper industries facing the coming information era. Although it is not the intention to associate this project with any particular companies or interests, some specific research of particular interest to individual companies can be arranged separately.

With projections for the future, the commencement of this project will help to establish an expertise center at IPST in the approach flow system areas and eventually for the whole wet end papermaking processes.

Acknowledgments

First, I would like to thank Professor David Orloff for suggesting this interesting field to me.

I am very grateful to Dr. David White and his papermaking PAC members, especially Mr. Richard Reese, Mr. Louis M. Vance, and Mr. Karl Christianson, who serve as the approach pipe system subcommittee.

It is my pleasure to have the privilege to work at IPST with so many wonderful faculty, research staff, and students. Part of the inspiration of getting evolved in this area is due to Professor Cyrus Aidun's recent success in applying numerical procedures to the coating and headbox analyses for our paper industries.

My utmost gratitude is due to Mr. Seppo Laaksonen, Dr. Jay A. Shands, Mr. Michael MacGregor, and the engineers working with them; their tremendous support and generosity during the preparation of this proposal mean the most to me.

Contents

Title page	1
Abstract	2
Acknowledgments	3
Contents	4
List of Figures	7
List of Tables	8
1 Introduction	9
1.1 Overview	9
1.2 Project Objective	11
1.3 Project Outline	12
2 Evaluation of Industry Needs	13
2.1 Flow-Induced Vibration	13
2.2 Fluid Flow Control	14
2.3 Deaeration Systems	14
2.4 Other Areas	14
3 Current Guidelines	21

3.1	Stuff Box	21
3.1.1	Valmet's Recommendation	21
3.1.2	TIS' Recommendation	22
3.1.3	Voith's Recommendation	23
3.1.4	Beloit's Recommendation	24
3.2	Wire Pits and Silos	25
3.2.1	Beloit's Recommendation	26
3.2.2	Voith's Recommendation	28
3.2.3	Valmet's Recommendation	29
3.3	Fan Pump	30
3.3.1	Voith's Recommendation	30
3.3.2	Beloit's Recommendation	31
3.3.3	TIS' Recommendation	31
3.4	Piping Arrangement	32
3.4.1	General Recommendations	33
3.4.2	TIS' Recommendation	33
3.4.3	Voith's Recommendation	34
3.5	Flow-Induced Vibration and Variations	35
3.6	Location of Valves	37
3.7	Elbow	38
3.7.1	Voith's Recommendation	38
3.7.2	TIS' Recommendation	38
3.8	Discussions	39
4	Research Approaches	41
4.1	Engineering Approach	41
4.2	Displacement/Pressure (u/p) Formulation	43
4.3	Pressure Pulsation Attenuator	45
4.4	Pipeline Simulation	46

4.5	Silo Design	51
4.6	Vortex Forming	51
4.7	Application of Fluidics and Hydraulics	52
4.8	Unsteady Flow in Piping System	52
5	Research Planning	56
6	Conclusions	58

List of Figures

3-1	Stuff box arrangement.	23
3-2	Mixing pipe arrangement.	32
4-1	Pressure pulsation attenuator mathematical model.	46
4-2	Analogy to electrical devices.	48
4-3	Silo design.	49
4-4	An overview of the computer simulation of the approach flow system (eventually the whole wet end processes.)	50
4-5	Development of vortices.	51
4-6	Prandtl Diffuser.	53
4-7	Tesla's Diode.	53
4-8	The velocity profile is changed by varying the control input.	54
4-9	Turbulence amplifier.	54

List of Tables

2-1	Sample #1 survey results.	15
2-2	Sample #2 survey results.	15
2-3	Sample #3 survey results.	16
2-4	Sample #4 survey results.	16
2-5	Sample #5 survey results.	17
2-6	Sample #6 survey results.	17
2-7	Sample #7 survey results.	18
2-8	Sample #8 survey results.	18
2-9	Sample #9 survey results.	19
2-10	Sample #10 survey results.	19
2-11	Sample #11 survey results.	20
5-1	Tasks and time line.	57

Chapter 1

Introduction

1.1 Overview

The approach pipe (or flow) system is comprised of numerous individual components between the stock preparation section and the headbox [35] [38] [23]. These components include fan pumps, piping, deaeration system, attenuator, pressure screens, cleaners, control valves and white water recycling systems. The effects of each component in the approach pipe system will directly influence the performance of paper machines.

As the development of more high production rate forming devices and short distance forming units (such as hydraulic headboxes and twin-wire forming sections) [17], the pressure pulsation tolerance and consistency fluctuation within the stock (mixture of wood fibers, chemical additives, and water) are getting more strict. In fact, the good performance of stock approach pipe systems is essential to the smooth operation of the entire paper machines with higher and higher machine speeds.

From a design standpoint, the stock approach system is one of the most critical areas of the paper machine and is often called “plumbers’ nightmare.” The current design guidelines are normally used to avoid the following difficulties:

- non-uniform fiber delivery;

- unstable flow, pulsations and surges;
- formation of stack lumps from stagnant zones, trapped air, rough surfaces; and
- vibration.

Although the arrangement, design, and operation of stock approach equipment will vary greatly from mill to mill and machine to machine, and the available guidelines and research information are often found to be inadequate and even confusing [36] [20] [37] [21] [14], there is no tool available to analyse the approach flow system as a whole under the circumstance of component changes, consistency and stock variations [11] [12] [39]. Therefore, to provide engineers the general design guidelines, more feasible analysis tools for both the specific components within approach flow systems and the whole system design are imperative.

It is the intention of this project to identify the fundamental research areas of approach pipe systems [32] and to provide the state-of-art solution techniques. The research results and procedures shall be widely applicable to both paper machine suppliers and mills.

In order to establish a robust and worthwhile project in this area, the needs and interests of the IPST membership companies were investigated, and based on the available published research results, the following three main research areas are identified:

- **flow-induced vibration**, including pressure pulsation and dynamic analysis of approach pipe systems [2] [3] [34];
- **fluid flow control**, including chemical additive (such as retention aids) mixing [25] [15], uniform consistency, stock and white water mixing; and
- **deaeration systems**, including cavitation, flow separation, and deculator system [11] [26].

The other areas related to approach pipe systems are surface finish [24] and pipe system design. The surface finish problem is mainly an issue of metallurgy and corrosion analysis; therefore it is not considered as one of our main research focuses.

The comments from papermaking PAC members were gathered through an informal telephone survey.

1.2 Project Objective

In engineering sciences, much effort has gone into the application of computer simulations. With the development of more powerful computers and more effective computational procedures, the traditional hydraulics and fluidics are merging with the concepts of computational mechanics [28]. We will, through this research project, develop computer simulation models for the field engineers to use in accordance with the specific mill and machine arrangement. The computer surrogates will contain:

- the mixing simulation within the pipe for fibres, water, and chemical additives;
- the computer simulation of individual components within the approach pipe system;
- the nonlinear dynamics computer simulation of the hydraulic design of approach flow systems; and
- the pressure pulsation simulation.

The specific objectives of this project are:

- to optimize the pressure pulsation attenuator for all ranges of frequencies, especially the lower range;
- to better understand the white water silo design;

- to better understand the mixing between stock and white water before the fan pump;
- to better understand short- and long-term consistency variations;
- to optimize the pipe system design including the location of valves, elbow, and pumps; and
- to develop a nonlinear dynamic model including the disturbance or perturbation dampening mechanism.

1.3 Project Outline

Based on the evaluation of our membership industry needs, we will include three steps in this project.

- Step 1: To identify the problems of individual components within approach pipe systems and to form corresponding computer simulation models;
- Step 2: To incorporate all approach pipe system components into a whole computer model and to develop an algorithm of computer system design simulations; and
- Step 3: To implement the developed software in any of the test approach pipe systems within our membership companies and to improve the current TAPPI TIS guideline (if necessary, individual company's guideline as well, depending on the separate arrangement.)

Chapter 2

Evaluation of Industry Needs

Stimulated by some membership industries' research needs [32], a telephone survey was conducted on a potential project in the areas of approach pipe systems.

The following topics are discussed: fan pump, flow stability, flow-induced vibration, piping, valves, recirculation, cleaners, pressure screens, chemical additive mixing, consistency control and design issues. However, discussions are focused on the aforementioned three main issues; i.e. **flow-induced vibration, fluid flow control and deaeration systems.**

The papermaking PAC members were asked how important these areas are, and what aspects of approach pipe systems are of most interest to them. In addition, they were asked to comment on the other areas related to approach pipe systems.

2.1 Flow-Induced Vibration

Ten out of 11 interviewees agree that this is an important issue. It is reflected in their comments that low frequency pulsation is more difficult to attenuate. In general, the vibration of the approach pipe system will be introduced to the headbox and eventually causes MD and CD base weight variations. The problem should be particularly considered for hydraulic headboxes. The sources of pulsation could be induced

by insufficient pipe supporting systems, flow-induced vibration, defective rotors, and acoustic resonance with the flow.

2.2 Fluid Flow Control

Almost all papermaking PAC members I talked to consider this area to be interesting. It was pointed out that the uniform consistency needs to be well understood. The flow pattern which influences the stock consistency and flocculation conditions, thin stock, thick stock, and chemical additive mixing are of most interest to these industry representatives. They feel that the existing guidelines are inadequate and more hydrodynamic parameters are needed in practice.

2.3 Deaeration Systems

Six interviewees think that this is not an important issue in their perspective, compared with five others on the other side. However, this problem is dependent on the paper grades that individual mill and machine produce. For light weight grade paper machines, it is still an issue of concern. Some PAC members mention the need for a deeper understanding of cavitation and flow separation problems within different pipes. The silo and wire pit are also of some interest. Some mills found that whether or not to have deculator systems did not make much difference, and in order to save room space, these deculators were withdrawn.

2.4 Other Areas

In addition to the three main topics, some papermaking PAC members commented on the system design problem. The concern is about the placement of various components, including the system design for new machines in old mills.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Less tolerance for MD and CD base weight variation as the machine speed increases	
Flow control	Important	Machine chest, blend chest, pressure screen, fan pumps, and valves	Guideline inadequate
Deaeration system	Important	Flow consistency, all kinds of mixing problems, more hydrodynamic parameters	Pipe elbow cavitation needs to be investigated
Other areas	Systems design is an important area	Placement of various components	

Table 2-1: Sample #1 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Pipe support and headbox vibration causes MD & CD base weight variations	Press section dynamic behavior may affect the headbox
Flow control	Important	Retention aids mixing, silo water level and pressure variation	
Deaeration system	Important	Fan pump, multisection pressure drops	
Other areas			

Table 2-2: Sample #2 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Influence on the headbox	
Flow control	Important	Good way of consistency control, zero variation	
Deaeration system	Important		
Other areas		System design, not enough space for various components	Air deculator has limited effects

Table 2-3: Sample #3 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important		
Flow control	Important	Thin stock, thick stock mixing, fan pump	
Deaeration system	Not so important		Deculator is good for lightweight print
Other areas			

Table 2-4: Sample #4 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Not so important		
Flow control	Important	Retention aids mixing, uniform consistency, thin stock, thick stock mixing	
Deaeration system	Not so important		Depending on different mills
Other areas			

Table 2-5: Sample #5 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Low frequency vibration affects the headbox and is difficult to deal with	High frequency vibration is easy to fix
Flow control	Important	Swirling affects additive & stock mixing, consistency, CD base weight variation	Poor guideline
Deaeration system	Not so important		
Other areas			Surface finish is a CH.E. problem

Table 2-6: Sample #6 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important		More and more interests
Flow control	Important	Machine chest, consistency control, and faster silo water	
Deaeration system	Not so important	Pipe design	
Other areas			

Table 2-7: Sample #7 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Pressure pulsation and recirculation line	
Flow control	Important	Thick stock & white water mixing, uniform mixture, and where to put additives	
Deaeration system	Important	Deculator system, Silo and wire pit	
Other areas			

Table 2-8: Sample #8 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Critical	Fan pump pulsation	
Flow control	Critical	Short circulation system on paper machines	
Deaeration system	Critical		
Other areas		Fan pump design	The design of <i>entire</i> system is of interest

Table 2-9: Sample #9 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important	Too much pressure drop, MD base weight variation	
Flow control	Important	Mixing velocity, stock & white water mixing, headbox circulation line	
Deaeration system	Important	Upset fan pump, too much pressure drop, cavitation, diffuser, MD variation	
Other areas		Fan pump cracks	Practical side of research

Table 2-10: Sample #10 survey results.

Area of study in approach pipe systems	How important is this area of study?	What aspects are of interest to your industry?	Other comments
Flow-induced vibration	Important		
Flow control	Important	Thick stock and thin stock mixing	
Deaeration system	Not so important	Pipe design	
Other areas			Hope to know more about how we are doing

Table 2-11: Sample #11 survey results.

Chapter 3

Current Guidelines

The design guidelines of approach flow systems are results of accumulated field experiences with installations, combined with basic hydraulic principles. These guidelines are generally recommendations for good system designs and should not be misconstrued as absolute design parameters. Therefore, for each individual system, due to the mill condition, specific recommendations are necessary.

Recommendations of TAPPI TIS, Valmet, Voith, and Beloit's guidelines on some approach pipe components' design are extracted in this chapter [36] [20] [37] [21] [14]. In the discussion section, we compare these design recommendations, and rationalize why these guidelines are not adequate, how some of them conflict, and what the future work will be to make the design process more practical and mill-specific.

3.1 Stuff Box

To ensure a stable heavy stock supply to the headbox approach pipe systems, some design guidelines suggest the proper use of a stuff box (shown in Fig. 3-1.)

3.1.1 Valmet's Recommendation

In Valmet's engineering instructions [21], the following two criteria are proposed:

1. General

The thick stock is fed into the fan pump suction either with stuff box or pump. The stock (controlled about 3% consistency) is fed through basis weight valve and quick release, or only through quick release valve, to the fan pump suction side.

2. Stuff box construction

The stuff box shall be placed at least 4.5 m (14.8 ft) above the white water off machine silo level to ensure sufficient inlet flow speed and pressure of the thick stock.

The connection of the thick stock inlet pipe and feed pipe to the stuff box should be made with a conical pipe to calm the thick stock flow in connection with the stuff box.

In regard to the optimum flow conditions of the fiber suspension, the stock inlet connection is situated in one end of the stuff box bottom, discharging connection in the center compartment and overflow connection in the far end.

The overflow amount of thick stock in the stuff box can be best adjusted with the adjustable-speed pump between the machine chest and stuff box, and thus avoid too much overflow from the stuff box back to the machine chest. Suitable overflow amount is 10 – 20% of the inlet flow. The overflow shall take place laminarily.

The basis weight valve is to be dimensioned for its best possible operational range and placed at least 1.5m (4.9 ft) below the wire pit liquid surface to avoid risk of cavitation. (Dimensioning instructions for stuff box is referred to in ref. [21])

3.1.2 TIS' Recommendation

In the TAPPI 1995-1996 Technical Information Sheets (TIS), the following guidelines are listed:

- Uniformity of basis weight in the machine direction can be no better than the uniformity of fiber supplied by the thick stock pipe. Slurry consistency, volume, and stability must be controlled with precision.




Figure 3-1: Stuff box arrangement.

- Monitor flow with stuff box or magnetic flow meter.
- Locate stuff box as close as possible to the pump suction.
- Figure 3-1 shows the stuff box arrangement.

3.1.3 Voith's Recommendation

If possible, the thick stock to the inlet of the fan pump should be controlled by means of a constant level (stuff) box [36].

- This box must be designed to avoid dead corners or uneven flow characteristics, while allowing a free surface to provide free air an opportunity to be released.
- When the stuff box is positioned very near the machine chest, the constant overflow can be returned directly to the machine chest.

- Use of a constant overflow provides a slight cushion against minor upsets in the thick stock system, and helps avoid foam or dirt build up on top of the stock.
- In order to provide sufficient dP for the basis weight control valve, the stuff box level should be 4m (13 ft) above the silo/wire pit level from which the fan pump draws its water.
- The control valve can be either a motor operated V-port ball valve or a special inclined regulating gate valve (with a narrow gate).
- Regardless of the design of the valve, it must be located below the silo/wire pit level, to avoid cavitation in the line. For best response time, the valve should be located as close to the fan pump as feasible.

3.1.4 Beloit's Recommendation

A stable system begins with a stable flow of heavy stock to that system. Proper use of a stuff box is the best way to insure this stability. By feeding the bottom of one end, discharging to the machine through a vertical dropleg from the center compartment and overflowing the far end, the box accomplishes five things:

- It eliminates much of the free air in the stock.
- It isolates the refining system from the headbox flow loop, minimizing the effects of pulsations from the preceding system. (Valves, Refiners, Pumps, etc.)
- It allows proper back pressuring of refiners, independent of head and flow requirements to the machine.
- It provides a constant head reference for the basis weight valve.
- It allows relatively constant thick stock flow to the refiners by bypassing the excess back to the machine chest.

Correct stuff box operation can be achieved with the following guidelines [14]:

- All interior surfaces in contact with stock or additives must be adequately corrosion resistant. All interior welds and surfaces must pass cotton tests.
- Eight seconds deaeration time are required from points “X” to “Y.”
- Liquid level is to be 180 to 240 in (4500 to 6000 mm) above silo liquid level.
- The minimum submerged depth in feet should equal the maximum velocity in fps at “E” or 48 in (1200 mm), whichever is greater.

Notice that the basis weight valve in the machine supply dropleg must be located at a low level to insure submergence and reduce valve cavitation. This prevents erratic pressure pulsations which accompany cascading flow, as well as promotes line cleanliness. Always overflow the stuff box in the direction of flow to eliminate possible foam build up. The stuff box should be located as close as possible to the silo to minimize the length of piping to the fan pump suction.

3.2 Wire Pits and Silos

The other necessary supply to the headbox approach pipe system is the white water from wire pits and silos, which are the major factors in system stability. Besides being a collector for former drainage, they provide a stable suction head for the fan pump and act as a deaeration device.

In order to maintain stock consistency in the machine chest, no return flow or make-up flow should be fed into this chest without having its consistency controlled.

The consistency control, as well as any brush refiners, should be positioned before the machine chest. This will allow the large volume of the chest to act as a buffer against consistency variations, as it mixes and equalizes the stock.

This requires an adequate mixing action within the machine chest to avoid separation of stock and water. Inefficient or faulty consistency control after the machine chest will have a direct effect on MD weight variations as well as CD profiles.

The use of properly designed wire pits and silos will provide deaeration and stability. Two basic types of silos are the under- and off-machine silo. The design criterion is to remove free air, to provide a constant fan pump head without vortexing, to provide constant back pressure, and to have a receptacle for introduction and deaeration of make-up waters.

3.2.1 Beloit's Recommendation

Beloit is concerned with the design of wire pits and silos primarily because of their utility in providing deaeration and stability. A considerable amount of air (2–4% by volume) is entrained in the white water in passing through the forming wires. This is unavoidable. Most of this air can be removed, however, with proper wire pit and silo design techniques [14].

The two basic types of silos are the under-machine type, where the pit is located directly below the former and contained within the sill beams, and the off-machine silo [14], located on the drive side of the former with connecting flow channels to the saveall troughs. The basic requirements are the same for either, and are independent of the former type for proper operation.

The under-machine type is normally used to save space on conventional Four-drinier machines. Downspouts discharge the water drained by the table elements into the channel at the breast roll end of the pit. The flow is directed to the couch end at slow average velocities (1 to 1.25 feet per second, or 0.3 to 0.4 mps) where the flow reverses and is returned to the silo located at the breast roll end. The relatively long period of open channel flow is desirable to release air and dissipate turbulence (up to 60 seconds if possible).

The off-machine silo is often used when clays and other fillers are present and with

most twin-wire arrangements. Channels are often shortened and some deaeration time sacrificed to prevent settlement of filler. A 30-sec dwell time is still minimum with this design for flow stability. An inherent feature of the off-machine silo is the automatic separation of table drainage and shower water.

The following design principles are offered as guidelines:

- The minimum dwell time for deaeration in the flow channel is 30 sec at the required velocities [14]. (60 sec is a desirable target to achieve maximum deaeration if filler separation is not a factor.)
- Liquid level in channel should be 6 to 24 in below bottom of former saveall to prevent possible flooding of the saveall pans.
- The bottom floor should slope downward as shown, to maintain self-drainage at shut down.
- Typical slopes, shown upwards to prevent air accumulation and subsequent slime build up.
- Adjustable weir to permit level control at least 6 in (150 mm) below to 12 in (300 mm) above design weir setup dimension.
- A minimum continuous silo overflow of approximately 1000 gpm is recommended to maintain a stable and foam free liquid level at the fan pump suction.
- Assuming 100% of total gallonage through wet end downspouts, use 1.25 fps (0.4 mps) to find liquid depth. (Maximum for good deaeration is depth 3 to 5 ft or 0.9 m to 1.8 m). (Nominal design depth should be 42 in.)
- All interior surfaces of the silo and wire pit to be tile-lined or equivalent.
- Use line size giving 6.0 to 8.0 fps between basis weight valve and fan pump suction.

- Alt. 1 of section Y-Y or Alt. 2 of section Y-Y can be used for entrance into the flow channel [14].
- Use Alt. 1 of section X-X for single dilution system.
- Use Alt. 2 of section X-X for double dilution system.
- Outlets may be positioned at any 90° angle to the silo.
- Use baffle with double dilution to prevent migration. Baffle height should be approximately 3.0 ft above top edge of pump suction.
- The end of pipes going concentric to the pump suction should be cut at a 30° to 45° angle to prevent “burping.”

A properly designed wire pit/silo arrangement will remove free air, provide a constant fan pump head without vortexing, provide constant back pressure for the basis weight valve, and provide a receptacle for introduction (and deaeration) of make-up waters. A properly designed wire pit/silo arrangement should reduce air content in stock to under 1.0%.

3.2.2 Voith’s Recommendation

The level of the white water supply reservoir (silo, wire pit, or seal pit) must be kept constant. Variations in this level will directly effect the quality of the final product [36].

- This is best accomplished by means of an overflow. This allows a cushion for sudden process changes, and long-term drainage variations.
- The maintenance of a constant level is essential. This level provides the inlet pressure against the fan pump and the back pressure against the basis weight control valve and various return flows.

The white water supply reservoir must provide adequate deaeration of the water.

- Retention time should be 0.5 to 1.0 min or greater.
- Downward velocities should not exceed 0.5 fps, to allow air a chance to rise to the surface.
- Maximize surface area to provide maximum opportunity for the release of air.
- Discharges into the reservoir should avoid high velocities and “waterfalls” that may entrain additional air.

Reservoir design must avoid stagnant areas (dead corners). Whenever possible, if space is available, the use of a white water silo over a wire pit or tank is recommended.

- This minimizes the potential cascading of white water.
- Reduction in air entrainment reduces the need for and expense of foam retardants.
- Inlet pressure to the fan pump is increased, reducing head and energy requirements.
- Operation of an auxiliary screen (vibrating) is enhanced as its discharge (if set on the machine room floor elevation) can be directed into a flooded collection tank.
- Start-up requires less “filling” of the system. Hence, stable operation is achieved more readily.

3.2.3 Valmet’s Recommendation

The silo is another area in which sufficient retention should be allowed for the liberation of air. The downward velocity in the silo should be around 0.5 ft/sec to allow

entrained air to escape and the retention time should be approximately 60-90 sec. Often, the silo level is raised in order to increase the NPSHa for the fan pump or mixing pump. This is detrimental to the process because the retention time is lowered and the air must travel a greater distance to be liberated, possibly worsening the problem. The tray water must not be allowed to cascade into the silo for the same reasons indicated in the overflow lines.

3.3 Fan Pump

In sizing a fan pump, care must be taken that the pump will operate at a maximum impeller rpm over the entire range of flows and consistencies. There are two types of fan pumps, one is the variable speed centrifugal and the other is the constant speed one.

3.3.1 Voith's Recommendation

For the variable speed pumps, the following guidelines are suggested:

- Vane frequency at low rpm conditions should not be less than 60 Hz.
- Normally used when variation in flow downstream of the fan pump is not detrimental to system performance. Such as no flow sensitive cleaning equipment, double dilution system, or a modified bypass system (if cleaners are not extremely sensitive to flow variations a small bypass can be utilized after the cleaners to control a dP range across the cleaners, while offering variable speed pump flow control to the headbox.)
- Energy efficient.
- Simplified, cleaner, and smaller approach flow system, through the elimination of bypass flows and throttling control valves.

- Reduce opportunity for pulsation generation.
- Reduce opportunity for consistency variations.
- Smooth headbox pressure control.
- During operation, the high points of the pump casing should be bled continuously for air.

3.3.2 Beloit's Recommendation

- Pumps should be selected for a maximum impeller rpm to help raise the frequency beyond the troublesome area.
- The impeller should have a maximum number of vanes.
- The impeller vanes should be split, staggered, and skewed if a double suction pump is selected.
- The impeller must be properly balanced and obviously must not operate near critical speeds. The impeller must be hydraulically as well as mechanically balanced; that is, there should be provision for equal flow through each of the impeller channels.
- Impeller deflection must be minimized.
- The suction head of the pump should well exceed maximum NPSH ("Net Positive Suction Head") requirements.

3.3.3 TIS' Recommendation

- Double suction type; split impeller with staggered vanes is recommended.
- Variable speed drive with good controls is recommended.




Figure 3-2: Mixing pipe arrangement.

- If oversized, avoid excessive throttling; reduce impeller diameter (check pump manufacturer's recommendations) or reduce speed.
- The inlet should be large to maintain a low velocity.
- Locate inlet to obtain a symmetrical flow to the pump whenever possible.

3.4 Piping Arrangement

Proper flow velocities must be maintained in any piping system. As stock travels through a system, it has a tendency to flocculate. If the proper velocity range is maintained, the stock will be less likely to flocculate and remain well mixed without creating undue turbulence.

Suppose we now have the uniform flows from thick stock, white water, and chemical additives, the mixing before the fan pump will determine the final stock approaching the headbox. There are two ways of mixing the lines shown in Fig. 3-2, one is to use concentric design and the other is to use an alternate top entry arrangement.

For the concentric design, the velocity of thick stock is higher than the white water from the wire pit and silo. For the pipe intersection, less than 45° is recommended to avoid burping.

One of the most important design considerations for this system is how to provide the best mixing of cleaned stock with white water in the fan pump. Cleaned stock normally increases the velocity of the mixture as it flows toward the fan pump, the final mixing takes place in the pump.

3.4.1 General Recommendations

- Make pipe lines as short as possible.
- Maintain flow velocity in the range of 5 to 15 ft/sec.
- Use noncorrosive pipe with smooth inside finish.
- Grind internal welds, remove weld spatter and polish with fine abrasive to assure acceptable smoothness. Check for residual roughness using the cotton ball test, particularly for pulps which easily form lumps and strings.
- Pipes should fit together smoothly. Fit gaskets carefully to avoid protrusion into the flow. Particularly between screens and headbox, use ground metal-to-metal flanges (Metlap, Vanstone or equivalent).
- Avoid stagnant pockets of stock.
- Install drains at low points. Drain plugs should be flush with the inside wall.

3.4.2 TIS' Recommendation

- Piping to the headbox header should consist of a straight length which is two or more pipe diameters long and is preceded by a long radius elbow, Venturi elbow, or gradual transition.
- Slope pipes upwards (1 in or more per foot) from the fan pump to the header to eliminate air pockets. This will also give better back drainage when the fan pump is shut down.

- When it is impossible to maintain a continuous upward slope to sweep out air pockets, high points (such as the top of a pressure screen) should be vented continuously. Successful venting, of course, requires that the vented area is always above atmospheric pressure.
- High flow velocities (10 ft/sec and faster) will sweep air out of lines that do not slope upward.
- Avoid air entrainment by cascades or vortices.
- Consider removal of troublesome air by a vacuum system.
- Adjustment of the recirculation flow from the end of a side entry tapered header can be overly sensitive if this line and valve are over-sized. Each header is designed for a specific recirculation, which is typically between 2 and 10% of the headbox flow. The line and valve should be sized to pass approximately one and a half times the design recirculation with the control valve fully open.
- A sight flow indicator on the header will assist in adjustment of the recirculation flow.
- Walls should diverge from the mean flow direction at less than 5° to avoid separation, and walls should converge at less than 45° .

3.4.3 Voith's Recommendation

As a general rule, all horizontal piping should be up hill (in the direction of the flow).

- Thick stock (3 – 4%) piping should be set at a minimum of 1.5 in rise per foot.
- Short runs of low consistency stock flow (0.25 – 1%) may be set at 0.5 in rise per foot.

- Pipe velocities (other than controlled mixing points) should be no less than 6 fps to prevent settling of stock and slime generation.
- Provide for deaeration all high points in the piping lines. Deaeration lines should be left slightly open at all times. Air vent lines should be separately piped to a free surface discharge point.

3.5 Flow-Induced Vibration and Variations

The wire pit and screens, the screens and headbox, and parts of the headbox may all form oscillating systems. In the case where the damping is not effective and the resonance occurs, these oscillations will approach the headbox and eventually cause basis weight variations by changing both head and consistency in the stuff box [36] [37] [21] [14].

It is essential that with the piping system layout, all high-fiber content flows are mixed in a uniform and smooth manner. The most efficient way to assure thorough mixing is through the use of a collecting pipe. This method mixes individual return flows and thick stock flow into a single pipe, prior to mixing with dilution water and being introduced into the suction of the fan pump. Assuming mixing considerations are properly followed, this method will eliminate the possibility of basis weight variations due to poor mixing, and it can also pre-mix the return flows some distance away from the fan pump. It is feasible to bring high fiber flows individually into the suction line of the fan pump. This requires additional space to achieve proper mixing conditions. Uncontrolled mixing by free discharge into the white water supply must be avoided at all times.

Headbox recirculation should be returned to the fan pump suction through the white water supply. This must be done in a manner that ensures uniform mixing, while offering a separation between the recirculation piping and the remaining piping in the approach flow system. Since pulsations introduced into the recirculation line

will have a direct effect upon the headbox, by disconnecting the recirculation from the rest of the system, the influence of pulsations in the pump and the collecting pipe upon the headbox can be greatly reduced.

To eliminate flow-induced vibration, the following general guidelines are commonly used [4]:

- Simple hangers alone are not adequate for headers that are located under the floor.
- Cross bracing must resist motion in the other two directions.
- Support or brace all piping, particularly at the headbox inlet.
- Support headers front and back; anchor to prevent CD vibration.

System sized for anticipated future higher volumes can be troublesome during the start-up period. Temporary modifications to the fan pump system should be considered, if a long period of sub-capacity operation is anticipated.

Immediately before the headbox (downstream of the screen) should be considered a critical piping area and all design guidelines should be stringently followed.

For step diffuser headboxes on Fourdriniers which are equipped with a P.E. Tank (Pulsation Elimination System), the tank serves as a hydraulic elbow, uniformly distributing the flow (as delivered to the tank) across the full width of the inlet. This provides a uniform distribution across the width of the machine. However, the tank will not completely compensate for inefficiently distributed retention aid, etc., and prior to the P.E. Tank, there should be a minimum of 3 pipe diameters of straight run.

For pressure headboxes with highly filled sheets, the possibility of flow separation (uneven filler distribution) in the elbows should be given special consideration. The straight run of pipe should be 8 pipe diameters (minimum of 5). If the straight run must be less than 6 diameters, then it is advisable to utilize a Venturi type

(aka acceleration) elbow. Further information is available on this design from Sulzer Papertec Middletown Inc. (SPMI) as required [36].

Separate branch lines by 2 (branch) pipe diameters. Enter at 60° or, better, 45°. Flow velocity should be low, less than 10 ft/sec. Match with main flow velocity. The inlet closest to the pump should be the highest consistency. Avoid branch lines entering diametrically opposite each other to prevent the flow of one affecting the discharge of the second. Arrange branch inlets to avoid asymmetrical flows into the fan pump suction.

3.6 Location of Valves

Valves control the pressure, rate of flow, and direction of fluids in accordance with basic principles of flow [36] [20] [37] [21] [14].

No valve should be within eight pipe diameters of the header entrance. Variable speed fan pump with good controls preferred. No in-line valve required. Coarse control by a suitable control valve. Operate valves within optimum operating range to avoid cavitation. Install valves before the screens, none between the screens and headbox.

Use suitable control valve on the fan pump bypass, sized to give a maximum of 20% run-around. A second recirculation line with coarse control can be used to bring the control valve into an optimum operating position.

Precede by 5 (preferably 8 or more) pipe diameters of straight pipe, and follow by 5 (preferably 8) pipe diameters of straight pipe before tees or elbows. In locations with space limitations, consider the use of vaned elbows.

Low elevations (submerged with respect to downstream pressure) for valves on return lines are advisable to minimize the possibility of surging, resulting from the trapped air after the valves. (This also minimizes negative pressures that can develop from back flow at shutdown). All recirculation lines should go into pipeline leading

to the pump suction, not into the wire pit.

All control valves should be located to ensure there is a back pressure at all times. This can be accomplished by locating all valves below the surface of the white water supply. Valves may be located as to have downstream flow at a higher elevation than the valve. When conditions dictate, a valve in a vertical flow downward line may be placed above the surface of the white water supply, if there is a downstream pressure drop greater than the physical elevation difference between the valve location and the white water supply. The guiding factor is that the flow in the approach flow system should be under positive pressure (except in specifically designed areas - i.e., deaeration tanks) at all times. Allowing flows in the approach flow system to generate a natural vacuum will increase free air entrainment, foam generation, and pulsation generation due to cavitation.

3.7 Elbow

3.7.1 Voith's Recommendation

Bends in flow should be made with long radius (Radius = $1.5 \times$ Normal Diameter), smooth flow elbows.

- Do not use mitred elbows due to the possibility of generating pulsations.
- Do not use vaned elbows due to the potential of fiber hang ups.

3.7.2 TIS' Recommendation

- Medium radius or vaned elbows are preferred. Medium radius elbows should be followed by at least two pipe diameters of straight pipe.
- Two successive medium radius elbows should not lie in planes inclined at 90° to each other.

- Mitred vaned elbows are recommended in locations where uniform flow is desirable and a straight pipe run is impractical. In circular pipes, the vanes can be welded into a band at the mitred section. The chord dimension can be selected to provide a convenient number of vanes for any size of elbow, but generally the vane spacing $c/3$ should lie between 2 in for small pipes and 5 in for large pipes. The leading edges of the vanes should be wider than the longest fiber, or $3/8$ in minimum, and the trailing edges rounded. End welds should be continuous and polished. A modification of the above design includes transitions to a rectangular mitred vaned section. This vaned section may be easier to fabricate and, by including a curved wall at the outside of the bend, gives better flow control. The number of vanes of a vaned bend (no miter) design is based on the feasibility of fabrication. All vanes must be carefully designed to avoid stapling of long fibers. Interior welds must be ground smooth and pass the cotton ball test.
- Discharge velocity from the ends of a tee should be greater than, or equal to, the entrance velocity; the distance may be valved to restrict and stabilize the discharge.

3.8 Discussions

Although many of the extracted guidelines from different companies and TIS are similar, they do not lack confusion and contradictions. In conclusion, the additional need in designing approach pipe systems is to have more precise and clearer guidelines, especially more key parameters based on deeper fundamental understanding. It is found that most of the existing guidelines are based on the past engineering experiences. Some of the design guidelines could be dated back for a few decades. Very little information is available on the nonlinear transient behavior of the approach flow system. A proper way to achieve the optimized approach flow system design is

really to have the computational tools to simulate individual components as well as the whole system.

The common guidelines for the stuff box is to arrange the valve and stuff box over the white water level. It is also conceivable that the stuff box can be treated as a pulsation isolator between the refining system and the flow to the headbox. Although certain hydraulic parameters are given in some guidelines, the detailed design is really hard to master based on these simple rules extracted from the mass conservation law. For example, how to optimize the vortex free stuff box free surface and the outlet is never achieved.

As far as the wire pit and white white silo are concerned, the design is focusing on the appropriate time for deaeration and stable water supply to the fan pump. However, the detail information such as the mixing region before the fan pump is really not available. In fact, Valmet has a very different silo outlet geometry recommendation from Beloit's.

Commonly, variable centrifugal pumps are recommended by paper machine suppliers, the needed controls of the pump are the stable inlet, impeller selections. However, the information on how to avoid the deflection of the vanes, how the fan pump reacts to certain variation during the papermaking process, and the detail design information for low consistency stock is not available. In addition, for the most critical part of pipe mixing, i.e. the mixing between the stock and white water before the fan pump, there has been very little in-depth research done in the past.

Also, the guidelines for flow-induced vibration should really be considered much more specifically than the current ones.

In practice, due to the specific mill conditions and the change of certain components within the approach flow systems, the existing guidelines are not always followed. Therefore, it is very much needed to have a computer model to handle the analysis of the whole approach flow system as well as the individual components.

Chapter 4

Research Approaches

The dynamics of the wet end includes pressure variation, flow, and consistency dynamics. The nonlinear dynamics computer modeling of the approach flow system will help to analyze and to design the system with the consideration of perturbation effects. The overall research approach would be two-fold:

- in-depth analysis of all components such as pressure attenuator, fan pump, elbow, pipe mixing section, white water silo, stuff box, deaeration system, pressure screen and cleaner within approach flow systems using finite element and other computational procedures; and
- incorporate the computer simulation results into a global nonlinear dynamic mathematical model, and obtain the solution with computational methods.

4.1 Engineering Approach

Starting from the Navier-Stokes equations, we can derive the following transient control equation between point 1 and 2

$$\int_1^2 \left\{ \frac{\partial \mathbf{v}}{\partial t} + \nabla \left(\frac{\mathbf{v} \cdot \mathbf{v}}{2} \right) + \frac{\nabla p}{\rho} + \nabla(gz) \right\} \cdot d\mathbf{r} = \int_1^2 \{ \mathbf{v} \times (\nabla \times \mathbf{v}) \} \cdot d\mathbf{r}. \quad (4.1)$$

where \mathbf{v} , p , ρ , $d\mathbf{r}$, g and z stand for the flow velocity, pressure, fluid density, streamline differential distance, gravity, and vertical Cartesian coordinate.

The r.h.s will be zero if either of the following holds:

- Positions 1 and 2 are on the same streamline; or
- $\nabla \times \mathbf{v} = \mathbf{0}$.

Notice here, in applying the above relation to our stock, the density change around the streamline might be considered. In the hydraulic control system, the pressure transient behavior within the pipe can be estimated by the above equation. Of course, the pipe flow direction is assumed to be the streamline direction in practice.

In engineering approach, pressure and flow dynamics have been modeled using Bernoulli equations [39]

$$p_1 = p_2 + \frac{L}{A} \frac{dQ}{dt} + \Delta p + s \quad (4.2)$$

where Q , L , A , Δp and s denote the flow rate, path length, cross section area, pressure source for the pipe containing the elevation difference between point 1 and 2, and any heads provided by pumps. Since pumps receive energy from outside the approach pipe system and are used to raise the energy level of the flow, the output of the pump constitutes the total source of energy available within the hydraulic system. Nevertheless, the total of the energy outputs from the system by components such as the drive motor and hydraulic cylinders is not equal to the total energy available from the pump because of friction and heat losses within the system. The proper determination of the correct pump for a given application essentially involves matching the pump to the required fluid power actuator giving consideration to pressure, flow rates, available drive speeds and power, efficiencies, cost, size, maintenance, and the operational characteristics of the pump and system. These include pump noise, vibration, natural frequency, and flow characteristics.

In addition to functioning in a stable, easily controlled manner, the fan pump system should afford a minimum possibility of forming agglomeration, or bundles, that cause sheet defects or breaks. Obviously, some detail analysis within the pump is necessary in addition to the engineering approaches.

Eq. (4.2) was often found to be inadequate, especially in the modeling of pump impeller vane deflection, screen vibration, and high frequency variations. Its modification is to include the continuous equation by introducing the fluid bulk modulus β .

For the consistency dynamics, the control equation can be often given as

$$\frac{dC_o}{dt} = \frac{1}{\tau}(C_i - C_o) \quad (4.3)$$

where C is the consistency, V is the tank volume, and $\tau = \frac{V}{Q}$ is time constant of the tank.

4.2 Displacement/Pressure (u/p) Formulation

A number of finite element formulations have been proposed to model an acoustic fluid for the analysis of fluid-structure interaction problems, namely, the displacement formulation (see Belytschko [8], Bathe and Hahn [6], Hamdi, et al [22], Belytschko and Kennedy [9], Olson and Bathe [30]), the displacement potential and pressure formulation (Morand and Ohayon [29]), and the velocity potential formulation (Everstine [18], Olson and Bathe [31], Felippa and Ohayon [19]).

Primitive variable formulations have received considerable attention because they do not require any special interface conditions or new solution strategies (for example, in frequency calculations and response spectrum analysis). With the ever-increasing availability of high-speed and large-capacity computers, this approach shows great promise in general applications to the solution of a broad range of problems (specifically nonlinear problems) [7] [40] [41].

In the mixed displacement/pressure formulation, we define a variational indicator

$$\Pi = \int_{V_f} \left\{ \frac{p^2}{2\beta} - \mathbf{u} \cdot \mathbf{f}^B - \lambda_p \left(\frac{p}{\beta} + \nabla \cdot \mathbf{u} \right) \right\} dV + \int_{S_f} \bar{p} u_n^S dS$$

where the variables are p , \mathbf{u} , and the Lagrange multiplier λ_p . We note that the first two terms correspond to the usual strain energy (given in terms of the pressure) and the potential of the externally applied body forces. The third term enforces the constitutive relation. The last term is the potential due to any applied boundary pressure on S_f .

Invoking the stationarity of Π , we identify the Lagrange multiplier λ_p to be the pressure p and obtain the governing equations, with $\mathbf{f}^B = -\rho\ddot{\mathbf{u}}$,

$$\nabla p + \rho\ddot{\mathbf{u}} = \mathbf{0} \quad (4.4)$$

$$\nabla \cdot \mathbf{u} + \frac{p}{\beta} = 0 \quad (4.5)$$

with the boundary conditions

$$\begin{aligned} \mathbf{u} \cdot \mathbf{n} &= \bar{u}_n & \text{on } S_u \\ p &= \bar{p} & \text{on } S_f. \end{aligned} \quad (4.6)$$

Applying the standard Galerkin discretization procedure, we have for a typical finite element

$$\begin{aligned} \mathbf{u} &= \mathbf{H}\hat{\mathbf{U}} \\ p &= \mathbf{H}_p\hat{\mathbf{P}} \\ \nabla \cdot \mathbf{u} &= (\nabla \cdot \mathbf{H})\hat{\mathbf{U}} = \mathbf{B}\hat{\mathbf{U}} \end{aligned}$$

where \mathbf{H} and \mathbf{H}_p are the interpolation matrices, and $\hat{\mathbf{U}}$ and $\hat{\mathbf{P}}$ are the vectors of

solution variables [5].

The matrix equations of the \mathbf{u}/p formulation are given as

$$\begin{bmatrix} \mathbf{M} & \mathbf{0} \\ \mathbf{0} & \mathbf{0} \end{bmatrix} \begin{Bmatrix} \ddot{\widehat{\mathbf{U}}} \\ \ddot{\widehat{\mathbf{P}}} \end{Bmatrix} + \begin{bmatrix} \mathbf{0} & \mathbf{L} \\ \mathbf{L}^T & \mathbf{A} \end{bmatrix} \begin{Bmatrix} \widehat{\mathbf{U}} \\ \widehat{\mathbf{P}} \end{Bmatrix} = \begin{Bmatrix} \mathbf{R} \\ \mathbf{0} \end{Bmatrix} \quad (4.7)$$

where

$$\begin{aligned} \mathbf{M} &= \int_{V_f} \rho \mathbf{H}^T \mathbf{H} dV & \mathbf{L} &= - \int_{V_f} \mathbf{B}^T \mathbf{H}_p dV \\ \mathbf{A} &= - \int_{V_f} \frac{1}{\beta} \mathbf{H}_p^T \mathbf{H}_p dV & \mathbf{R} &= - \int_{S_f} \mathbf{H}_n^{S^T} \bar{p} dS. \end{aligned}$$

In the \mathbf{u}/p formulation we interpolate displacements and pressure as independent variables, and we employ elements that satisfy the inf-sup condition. It is also important that the slip boundary conditions are introduced such that the requirements of mass and momentum conservation around the fluid boundaries and fluid-structure interfaces are satisfied.

Using the \mathbf{u}/p formulation for the solution of frequencies, many (exact) zero frequencies are calculated. The exact number of these zero frequencies can be predicted, and in the solution the eigensolver simply shifts over them [5]. Also, the number of zero frequencies can be reduced by use of the $\mathbf{u}-p-\Lambda$ formulation (see also reference [7]).

This displacement/pressure finite element formulation for the analysis of acoustic/slosh fluid-structure interaction problems can be used effectively in this project.

4.3 Pressure Pulsation Attenuator

Extremely low frequency basis weight variations, from 0.001 Hz to 1 Hz, are often related to thick stock flow. It is essential that the thick stock, at 3 to 4% consistency, be fed at a uniform flow rate and stable consistency to the inlet of the fan pump.




Figure 4-1: Pressure pulsation attenuator mathematical model.

To finally achieve the uniform and consistent stock flow to the headbox, a properly designed pressure pulsation attenuator has to be used to effectively eliminate both the low- and high-range frequencies.

The above-discussed formulation can be directly applied to analyze the pressure pulsation attenuator shown in Fig. 4-1. In fact, computation modeling of this sort can also be applied to obtain optimized designs of different components.

4.4 Pipeline Simulation

Pipelines are nonlinear devices. The flow of fluids in pipes resembles, to a certain degree, the flow of electric current in nonlinear resistances. Kirchoff's laws can be applied directly (see Fig 4-2), however, the Ohm's law is replaced by the nonlinear relation between flow rate Q and the friction loss ΔH

$$\Delta H = S(Q) = LC_2 \frac{4}{(3.6 \log(C_1 Q / 8d\nu))^2} \frac{Q^2}{d^5} \quad (4.8)$$

and

$$Q = S^{-1}(\Delta H) = \sqrt{\frac{\Delta H d^5}{LC_2}} \left(-2 \log \left(\frac{2.825\nu}{C_1} \sqrt{\frac{C_2 L}{\Delta H d^3}} \right) \right) \quad (4.9)$$

where C_1 and C_2 are the constants found from experimental results, and ν , L and d are the kinematic viscosity, pipe length, and pipe diameter.

The head loss ΔH can also be written as

$$\Delta H = f(Re, \frac{\epsilon}{d}) \frac{L U^2}{d 2g} \quad (4.10)$$

where Re , ϵ , and U are Reynolds number, surface roughness measure, and pipe flow mean velocity, respectively.

From the Karman-Prandtl equation, for smooth pipes, we have

$$\frac{1}{\sqrt{f}} = 2 \log_{10}(Re \sqrt{f}) - 0.8. \quad (4.11)$$

In actuality, the head loss will include the local head loss in turbulent flow, the head loss due to sudden expansion, the loss in elbow (or pipe bends), the loss at combining and dividing junctions. Of course, the concept of the equivalent pipe length can also be extended.

In the study of transient flow, especially pressure surges in long pipelines, there are close equivalents to the transmission line telegraph and telephone equations. In the approach pipe flow system, fan pumps, pressure screens, cleaners, and elbows can be simulated by different electrical devices.

Notice that to deal with the nonlinear relations in Eqs. (4.8) and (4.9), in practice iterative methods have to be used.

For the complex pipeline systems, we apply the following

Pipelines in Series:

$$\sum_{i=1}^N \Delta H_i = \sum_{i=1}^N S_i(Q) = \Delta H \quad (4.12)$$

Parallel Pipelines:




Figure 4-2: Analogy to electrical devices.




Figure 4-3: Silo design.

$$\sum_{i=1}^N Q_i = \sum_{i=1}^N S_i^{-1}(\Delta H) = Q \quad (4.13)$$

and Kirchoff's laws to *Partial Looped Pipelines*, *Branching Pipelines*, and *Pipeline Networks*. As discussed before, computational models of different approach flow system components are going to be used to get the simplified equations such as Eqs. (4.8) and (4.9). For example, in the analysis of the free vibration of fluid submerged impeller, the computational procedure with the \mathbf{u}/p formulation as described above is efficient and sufficiently accurate. A similar computational model can be applied to the other components as well. Finally, we can incorporate the equations such as Eqs. (4.8) and (4.9) into a global model of the approach flow system, and apply the computational nonlinear dynamics procedure to analyze the effects of individual components' variation on the system. A schematic hierarchy is shown in Fig. 4-4.




Figure 4-4: An overview of the computer simulation of the approach flow system (eventually the whole wet end processes.)




Figure 4-5: Development of vortices.

4.5 Silo Design

Due to the different silo design guidelines [37] [14], in this research project, we will develop a computer model to analyze some white water silo prototypes (shown in Fig. 4-3) and discuss the advantages and disadvantages.

4.6 Vortex Forming

Air entrainment in the stock can result in pressure variations, machine direction basis weight variations, slime and dirt spots, foaming, and pinholes. One of the interesting problems is the vortices forming during the discharge outlets of chests, stuff boxes, and wire pits (shown in Fig. 4-5). It is anticipated that proper CFD models can be used to optimize the design process.

4.7 Application of Fluidics and Hydraulics

Fluidics is the technology of employing the general fluid phenomena of wall-attachment and stream interaction in specially designed devices to perform the functions of sensing, logic, and control [28] [16] [10] [27] [1] [13]. Some of the control procedures will have the potential application to papermaking industries.

Major innovation in the utilization of fluids occurred in the 18th century as the Newcomen steam pump (1711) and Watt's steam engine (1769) were harnessed for the rapidly increasing power requirements of the industrial revolution. In 1904 a German aerodynamicist, Prandtl, proposed the control of flow separation in a wide-angled diffuser illustrated in Fig. 4-6. Nicola Tesla filed a patent in 1916 for a "Valvular conduit" which performed as a fluid diode, causing high resistance to fluid flow in one direction and low resistance in the opposite direction shown in Fig. 4-7.

Figure 4-8 shows the effect upon the velocity profile caused by shifting the separation point. It can be seen that the velocity of the flow near the outer wall is increased [33].

Figure 4-9 shows the turbulence amplifier. A laminar jet is produced from the supply port. When the jet is disturbed and becomes turbulent before reaching the outlet channel, the output signal falls from its previous value to a much smaller one. Notice that the jet does not become laminar again immediately on removal of the control signal, probably because of the feedback of turbulent flow from the region of the outlet channel towards the control ports. The delay is found to be four times the time for transport of a particle along the length of the jet.

4.8 Unsteady Flow in Piping System

Unsteady flow in piping systems is a common occurrence. Indeed, steady flow is so rare that one might question the advisability of devoting so much time to a study of its behavior. Although most of all hydraulic design is based on steady flow analysis and,




Figure 4-6: Prandtl Diffuser.




Figure 4-7: Tesla's Diode.




Figure 4-8: The velocity profile is changed by varying the control input.




Figure 4-9: Turbulence amplifier.

in many cases, the unsteadiness occurring in a pipeline system is of little consequence because of its transient nature and small magnitude of change, in paper industry, the unsteady flow within the approach flow piping is detrimental to the papermaking process.

The control equation for the transient behavior within the pipe can be written as [42]

$$\frac{\partial p}{\partial s} + \rho g \frac{\partial z}{\partial s} + \frac{4\tau}{d} = \rho \frac{dv}{dt} \quad (4.14)$$

where d is the pipe diameter, τ is the shear stress at the wall, and v is the average velocity. Notice that none of the existing research in this area deals with nonlinear dynamics involving consistency and pressure variations, although in practice the perturbation due to various sources can be detrimental to the manufacturing processes. It will be part of the approach flow system project to simulate the nonlinear variations.

Chapter 5

Research Planning

The following M.S. and Ph.D. projects could be generated from the research in this area

- (1) Computer Simulation of Approach Pipe System Dynamic Behaviors (M.S.)
- (2) Mixing Behavior of White Water and Stocks Before the Fan Pump (M.S.)
- (3) Mixing Behavior of Chemical Additives and Uniformity of Consistency (Ph.D.)
- (4) Flow Separation and Cavitation (Ph.D.)
- (5) Flow-induced Vibration of Approach Pipe Systems and Headboxes (Ph.D.)
- (6) Nonlinear Dynamical Behavior of Approach Pipe Systems Subjected to Perturbation (Ph.D.)

The fundamental research topics related to the above five projects are multidisciplinary. It includes the following hot subjects in computational mechanics areas:

- (1) Turbulence Theory and Nonlinear Dynamics
- (2) Fluid-Structure Interactions
- (3) Both Spatial and Temporal Stability of Numerical Procedures

It is justified that a funded project should be established in the approach pipe system area. This project will help to form an education and research center for study in this area as well as the whole wet end papermaking processes.

Once the research is funded, we will start by analyzing the individual components

	1	2	3	4	5	6	7	8	9	10	11	12	1	2	3	4	5	6
Pulsation attenuator	-	-	-	-	-	-												
Pipe flow mixture							-	-	-	-	-							
White water silo												-	-	-				
Elbow															-	-	-	-
Writing report												-						-

Table 5-1: Tasks and time line.

within approach flow systems. The following problems will be focused on first:

- pressure pulsation attenuator;
- White water silo;
- Pipe mixture;
- Fan pump;
- Elbow; and
- Stuff box.

The second stage will be two-fold, firstly, we will continue to analyze specific components within approach pipe flows; secondly, the whole system model will be developed and analyzed.

Although at this stage, it would be hard to exactly follow the time lines, Table 5-1 is used to illustrate the tentative planning of this project for the first one and a half years.

Chapter 6

Conclusions

Regardless of dampening features of individual headbox designs, it is important to minimize the system variations prior to delivery of stock to the headbox. This will maximize the capability of the headbox to provide a uniform and consistent delivery of fiber to the machine. The more stable the approach pipe system, the better the end product. In fact, in modern paper machine designs, consistency variations are of specific importance and it is nearly impossible to compensate for a swing in fiber flow within the short dwell time of any headbox. This will only be accentuated as the paper industry turns to more and more hydraulic headboxes and shorter forming sections.

From the information provided by papermaking PAC members and other resources, it seems that many possibilities exist for specific research focuses with the proposed project. In fact, some of them can be ideal candidates for external projects funded by individual companies or groups.

Based on the survey results and available guidelines from TAPPI TIS, Valmet, Beloit, and Voith, it is concluded that more in-depth research is imperative in this area. Since following the guideline does not mean trouble-free, and the details of the approach flow system must be determined for individual cases, including the type of plant, product, speed, and quality requirements for the specific application, the

development of computer simulators for the analysis as well as design purposes will contribute tremendously to the paper industry.

In summary, the need for this project is strong and the support from the industry is overwhelming. The main objective of this project is that through the development of computer surrogates, we will finally be able to achieve, maintain, and master the uniform rates and consistencies for all inflows, outflows, return flows, level controls, in-line mixing, i.e., the complete process within the approach pipe flow system even if the individual components and the whole system are under certain transient variation or perturbation during the papermaking processes.

References

- [1] *Pipework Design and Operation*. IMechE Conference Publications, 1985.
- [2] M. Barasch. Dynamic analysis of the approach flow system. *CPPA 75th annual meeting, technical section*, pages A33–A37, 1989.
- [3] M. Barasch. Dynamic analysis of the approach piping system. *Tappi Engineering Conference*, pages 73–80, 1989.
- [4] M. Barasch. Dynamic analysis of the approach flow system. *Pulp & Paper Canada*, pages 49–52, 1991.
- [5] K.J. Bathe. *Finite Element Procedures*. Prentice Hall, Englewood Cliffs, N.J., 1996.
- [6] K.J. Bathe and W.F. Hahn. On transient analysis of fluid-structure systems. *Computers & Structures*, 10:383–391, 1979.
- [7] K.J. Bathe, C. Nitikitpaiboon, and X. Wang. A mixed displacement-based finite element formulation for acoustic fluid-structure interaction. *Computers & Structures*, 56(2/3):225–237, 1995.
- [8] T. Belytschko. Fluid-structure interaction. *Computers & Structures*, 12:459–469, 1980.
- [9] T.B. Belytschko and J.M. Kennedy. A fluid-structure finite element method for the analysis of reactor safety problems. *Nuclear Engineering and Design*, 38:71–81, 1976.
- [10] R.P. Benedict. *Fundamentals of Pipe Flow*. John Wiley & Sons, 1980.
- [11] P. Boettcher. Headbox approach flow systems. *Stock Preparation Short Course*, pages 41–45, 1984.
- [12] D. Byers. Proper component fit is key design factor for headbox approach system. *Pulp & Paper*, pages 126–129, November 1991.
- [13] A. Conway, editor. *A Guide to Fluidics*. Macdonald & Co. Ltd., 1971.

- [14] Beloit Corporation. Headbox piping recommendations: Design information. November 1994.
- [15] M.W. Day and J.C. Kerr. Stock approach technology: Systems design. *Stock Preparation Short Course*, pages 91–95, 1988.
- [16] P. Dransfield. *Hydraulic Control Systems - Design and Analysis of Their Dynamics*. Springer-Verlag, third edition, 1981. Lecture Notes in Control and Information Sciences.
- [17] J.C.W. Evans. Paper machines in the year 2000: Higher speeds, new press designs. *Trends and Developments in Papermaking*, pages 50–51, 1985.
- [18] G.C. Everstine. A symmetric potential formulation for fluid-structure interaction. *Journal of Sound and Vibration*, 79(1):157–160, 1981.
- [19] C.A. Felippa and R. Ohayon. Mixed variational formulation of finite element analysis of acoustoelastic/slosh fluid-structure interaction. *Journal of Fluids and Structures*, 4:35–57, 1990.
- [20] Fluid Mechanics Committee Tappi. Headbox piping system: General design guide. *Technical Information Sheet(T.I.S.)*, 0410-06, 1995.
- [21] Valmet-Tampella Ltd. Board Machinery Group. Special requirements for the board machine short circulation. September 1985.
- [22] M.A. Hamdi, Y. Ousset, and G. Verchery. A displacement method for the analysis of vibrations of coupled fluid-structure systems. *International Journal for Numerical Methods in Engineering*, 13:139–150, 1978.
- [23] O.L. Heissenberger, Jr. Design aspects for approach flow systems. *Papermakers Conference*, pages 273–278, 1986.
- [24] M. Johnson. The headbox approach system. *Tappi Papermakers conference*, pages 515–522, 1991.
- [25] J.C. Kerr. Stock prep approach systems. *Stock Preparation Short Course*, pages 93–98, 1990.
- [26] K.D. Kurtz. Deaeration and the approach system. *Stock Preparation Short Course*, pages 179–193, 1994.
- [27] A. Lencastre. *Handbook of Hydraulic Engineering*. John Wiley & Sons, 1987.
- [28] C.B. Lester. *Hydraulics for Pipeliners*, volume 1: Fundamentals. Gulf Publishing Company, second edition, 1994.

- [29] H. Morand and R. Ohayon. Substructure variational analysis of the vibrations of coupled fluid-structure systems. Finite element results. *International Journal for Numerical Methods in Engineering*, 14:741–755, 1979.
- [30] L.G. Olson and K.J. Bathe. A study of displacement-based fluid finite elements for calculating frequencies of fluid and fluid-structure systems. *Nuclear Engineering and Design*, 76:137–151, 1983.
- [31] L.G. Olson and K.J. Bathe. Analysis of fluid-structure interactions. A direct symmetric coupled formulation based on the fluid velocity potential. *Computers & Structures*, 21(1/2):21–32, 1985.
- [32] D. Orloff. *IPST Internal Communication*, September 1995.
- [33] R.S. Powell, M.M. Smith, and M.J.H. Sterling. Robust on-line data validation for real-time monitoring of water distribution networks. In Č. Maksimović and M. Radojković, editors, *Computational Modelling and Experimental Methods in Hydraulics*, pages 279–288. Elsevier Applied Science, 1989.
- [34] M. Rajala. Viscosity perturbation damper connected with distribution header of papermaking machine headbox. *United States Patent*, 3865687, February 1975.
- [35] G.A. Smook. *Handbook for pulp & paper technologists*. Angus Wilde Publications, second edition, 1992.
- [36] J. Stadelmann. Design of approach flow systems. *Voith Inc.*
- [37] Valmet. Special requirements for the board machine short circulation. 1985.
- [38] Vender1. Stock piping principles and their effect on paper machine performance. 1976.
- [39] P. Virtanen, H. Koivo, and F. Cameron. Computer simulator for paper machine wet end. *Tampere University of Technology at Finland*, 1987.
- [40] X. Wang and K.J. Bathe. Displacement/pressure based finite element formulations for acoustic fluid-structure interactions. *International Journal for Numerical Methods in Engineering*, 40:2001–2017, 1997.
- [41] X. Wang and K.J. Bathe. On mixed elements for acoustic fluid-structure interactions. *Mathematical Models & Methods in Applied Sciences*, 7(3):329–343, 1997.
- [42] G.Z. Watters. *Analysis and Control of Unsteady Flow in Pipelines*. Butterworths, 1984.

